



The **Yoto Player** is a screen-free audio player for children. By placing a card into the player, it plays that audiobook through the speaker. The Innisfil ideaLAB & Library has two different **Yoto Players**: the regular and the mini.


The **Yoto Player** provides children with the opportunity to experience audiobooks independently. It is kid-friendly and intuitive for them to learn.

To borrow the **Yoto Player**, go to innisfilidealab.ca, and under the **Borrow** tab, select **The Library of Things**, then **Lendable Tech**, and scroll down to **Yoto Player**, clicking on **Place Hold**.

Getting Started:

Place the player on a surface so that the flat gray screen is facing towards you and the handle is at the top. To turn on the player, press the small, gray power button on the right side.

The player controls act differently depending on whether a book card is inserted or not. 10 different book cards are included with the mini player and 7 different book cards are included with the regular player.





Listening to a book:

To listen to a book, position the book card right side up and facing towards you, while placing it into the slot at the top of the player. The book will start to play right away.

To go to the previous chapter, press the top left knob. To go to the next chapter, press the right knob.

To adjust the volume, turn the left knob.

To fast forward through chapters, turn the right knob. Once at the desired spot, press the button to play it.

To pause the book, pull the card out of the player. When placed back in, the player will pick up where you left off.

To turn off the player, press and hold the power button for at least 3 seconds.

To learn more about **Yoto Player**, visit ca.yotoplay.com

more inside